


Technical Details & Accessories

Technical - Handles




TO UNLOCK HANDLES TURN KEY 180⁰ ANTI-CLOCKWISE

RE = RIGHT EDGE OF DOOR

VIEWS ARE SHOWN LOOKING ON FRONT FACE OF HANDLE LE = LEFT EDGE OF DOOR

SPINDLE DATA FOR ALL HANDLES WITH 8MM SQUARE SPINDLE



SPINDLE	DESIGNAL	ION

EXAMPLE

3rd AND 4th DIGITS WILL INDICATE LENGTH OF FULL 50 THREAD REQUIRED, TO A MAXIMUM OF 99mm (IN THE CASE OF PLAIN SPINDLES THIS WILL READ 'O')

5th, 6th AND 7th DIGITS WILL INDICATE BLANK LENGTH OF SPINDLE

EXAMPLE INDICATES AN 8mm THREADED SPINDLE WITH A BLANK LENGTH OF 70mm AND 50mm OF FULL THREAD